

Quick Start

NOTE: Connect VGA monitor and mouse before starting.


1. Overview
2. Connection
3. Start Up/Shutdown
4. Formatting a Disk
5. Setting Date & Time
6. Recording
7. Playback
8. Backup

NOTE: For more detailed information, refer to the Users Manual on the CD-ROM. You must use your PC or MAC to access the files.


Quick Start Guide

1. Overview


Check that your package includes the following:



Front Panel Description:



2. Connection



3. Startup and Shutdown

To startup your DVR:

1. Plug power adapter into DVR and electrical outlet. It is HIGHLY recommended to use a surge protector. The Power indicator LED on the front panel will turn red.
2. Connect a VGA monitor and mouse into the DVR. **NOTE: Monitor and mouse needs to be plugged in before starting.**
3. Switch the POWER button on the back rear panel. The Power indicator LED will turn blue. The unit will begin to start.

NOTE: Default password is 12345

Startup and Shutdown (cont.)

To shutdown your DVR:

- OPTION 1: Standard Shutdown
1. Enter the Shutdown menu by going to Main Menu > Maintenance > Shutdown.
 2. Select the Shutdown button.
 3. Click the Yes button.
 4. Turn off Power switch in back of DVR.



OPTION 2: Manual Shutdown (HK-RA216 Model Only)

1. Press and hold the POWER button for 3 seconds.
2. Enter the administrator's username and password in the dialog box for authentication.
3. Click the Yes button.
4. Turn off Power switch in back of DVR.

NOTE: Do not press the POWER again when the system is shutting down.

Formatting a Disk (cont.)

4. A confirmation message will appear on the screen. Click the Yes button to continue formatting process.



5. A format progress bar will be shown on the menu. After the disk has been formatted, the status of the disk will change to Active.



6. Click the Done button to exit out of Disk Management.

4. Formatting a Disk

NOTE: One hard disk drive (HDD) is already installed and formatted in this DVR.

A newly installed hard disk drive (HDD) must be formatted first before it can be used with your DVR. **NOTE: Formatting the disk will erase all data on it.**

To format a new disk:

1. Enter the Disk Management menu by going to Main Menu > System Configuration > Disk Management.
2. Select a disk to format. A disk that has not been formatted will show Error Detected as its status. If the disk is one that is newly installed, the status of the drive will show up as Non-Active and the Reformat button will change to the Add button.
3. Click the Add button.

Quick Start Guide

6. Recording

To setup quick recording schedule:

1. Enter the Quick Schedule Configuration menu by going to Main Menu > Recording Configuration > Quick Schedule Configuration.
2. Select the camera to configure from the camera drop down menu. If all the cameras are to be configured with the same settings, select All Cameras from the list.
3. Check the Enable checkbox to enable the recording schedule. If the checkbox is unchecked, the recording schedule will be disabled.
4. Check the 24/7 checkbox if you would like to record continuously or on event for 24 hours a day, 7 days a week. If you wish to schedule different time frames for Monday through Sunday, leave the 24/7 checkbox unchecked and skip to step 6.
5. Select Recording Type for 24/7 recording and move on to step 8. Recording type includes Continuous for continuous recording or On Event for recording when an event is triggered (i.e. from detected motion).
6. Select the start and stop time for each day of the week. The start and stop time are listed using a 24 hr cycle (i.e. 18:00 is equivalent to 6:00pm).
7. Select Recording Type for each day of the week. Recording type includes Continuous for continuous recording or On Event for recording when an event is triggered (i.e. from detected motion) for the selected time period.
8. Check the Enable Audio checkbox if you would like to enable audio recording along with the video. Audio can only be recorded if an amplified audio source is connected to the DVR.
9. Select the Save button to save the schedule settings and select Exit to return to the previous menu. Selecting the Exit button without clicking Save will quit out of the menu without saving settings.



5. Setting Date & Time

To setup date and time:

1. Enter the Time/Date menu by going to Main Menu > System Configuration > Time/Date.
2. Enter the correct date and time.
3. Click the Save button to save the setting.



7. Playback

Playback from Search:

1. Enter the Playback menu by going to Main Menu > Playback.
2. Set the search parameters by selecting cameras to search and date to search on.
3. The search results will be shown on the timeline with blue bars designating recorded files.
4. Select file and click the Play button to begin playback.



Playback from System Log:


1. Enter the System Logs menu by going to Main Menu > Maintenance > System Logs.
2. Select date from the Calendar to search for system logs in.
3. Select Search Type.
4. Click the Search button.
5. A list of results with your search criteria will be displayed. If applicable, select the video log to playback and click Play.
6. The recording will begin to play in the Playback interface.



8. Backup

To backup recorded files:

1. Enter the File Management menu by going to Main Menu > System Configuration > File Management
2. Select desired parameters to search for files to backup.
3. Select the files to backup. You may also click the Play button to verify that these files are indeed the ones you would like to backup. The total size of the files will also be shown on this menu.
4. Click the Files Backup button to access the Files Backup Menu.
5. Select device to backup to from drop-down list (USB Flash Drive, USB HDD, DVD Writer). If backup device is not recognized:
 - Click the Refresh button.
 - Reconnect device.
 - Check for compatibility from vendor.
6. The total available free space will be shown. If the free space is not sufficient, delete files from the storage device or insert a device with more available free space.
7. Click the Backup button to begin backup process. After the backup has completed, click the OK button.



Quick Start Guide

DS-7208HVI-S, DS-7216HVI-S

Version 2.0

NOTE: For more detailed information, refer to the Users Manual on the CD-ROM. You must use your PC or MAC to access the files.

HIKVISION USA, Inc.

A Division of Hikvision China

565 Brea Canyon Road, Suite A
Walnut, California 91789
techsupport@hikvision-usa.com